

INTERvention®

Farm Animal Care
Disinfectant Cleaner & Deodorizer

Ready to Use Wipes

KEEP OUT OF REACH
OF CHILDREN

**FOR BARN
& FARM USE**

EPA Reg. No. 74559-10
EPA Est. No. 74559-CAN-1

This product is a one-step germicidal disinfectant cleaner and deodorant designed for general cleaning and disinfecting of hard, non-porous environmental surfaces.

It cleans quickly by removing dirt, grime, blood, urine, mold stains, fecal matter and other common soils found in barns, farms, and animal transportation vehicles.

This product is designed for use on hard, non-porous environmental surfaces: chrome, glazed ceramic, glazed porcelain, glazed tile and stainless steel associated with high touch environmental surfaces, animal equipment, animal crates, automatic feeders, buckets, brushes, exterior surfaces of watering appliances, farm vehicles (hard, non-porous surface of), feed racks, foot baths, grooming equipment, handling equipment, pens, transportation crates, troughs and any hard non-porous washable (non-food contact) surface where disinfection is required. It also reduces odor-causing bacteria leaving surfaces smelling clean and fresh.

Claims

BACTERICIDAL IN 1 MINUTE:

Acinetobacter baumannii (Multi-Drug Resistant)
Bordetella bronchiseptica
Bordetella pertussis
Burkholderia cepacia
Enterobacter aerogenes
Enterobacter cloacae (New Delhi metallo- β -lactamase 1 (NDM -1))
Enterococcus faecalis (Vancomycin Resistant (VRE))
Enterococcus faecium
Escherichia coli
Escherichia coli O157:H7
Escherichia coli (Extended Spectrum Beta-lactamase (ESBL))
Escherichia coli (New Delhi metallo- β -lactamase 1 (NDM-1))
Klebsiella pneumoniae
Klebsiella pneumoniae (Extended Spectrum Beta-lactamase (ESBL))
Klebsiella pneumoniae (New Delhi metallo- β -lactamase 1 (NDM-1))
Klebsiella pneumoniae (Carbapenem Resistant (CRE))
Legionella pneumophila
Listeria monocytogenes
Pasteurella multocida
Pseudomonas aeruginosa
Pseudomonas aeruginosa (Metallo-Beta lactamase (MBL) positive)
Salmonella enterica (formerly known as *Salmonella choleraesuis*)
Serratia marcescens
Shigella dysenteriae
Staphylococcus aureus
Staphylococcus aureus Community Acquired Methicillin Resistant Genotype 400 (CA-MRSA 400)
Staphylococcus aureus (Methicillin Resistant (MRSA))
Staphylococcus aureus (Vancomycin Intermediate Resistant (VISA))
Staphylococcus aureus (Vancomycin Resistant (VRSA))

Reference Sheet

Manufactured by:
Virox Technologies Inc.
2770 Coventry Road
Oakville, ON Canada L6H 6R1
1-800-387-7578
virox.com | viroxanimalhealth.com



Staphylococcus epidermidis (Methicillin Resistant (MRSE))
Staphylococcus pseudintermedius
Stenotrophomonas (Pseudomonas) maltophilia
Streptococcus pneumoniae (Penicillin Resistant (PRSP))
Streptococcus pyogenes

FUNGICIDAL IN 30 SECONDS, UNLESS OTHERWISE NOTED:

Candida albicans – 1 minute
Microsporum canis – 1 minute
Trichophyton mentagrophytes

TUBERCULOCIDAL IN 1 MINUTE:

Mycobacterium bovis (BCG)

*VIRUCIDAL IN 30 SECONDS:

Adenovirus Type 8
Avian Influenza A Virus (H7N9)
Avian Influenza A Virus (H3N2)
Cytomegalovirus
Feline Calicivirus
Hepatitis B Virus (Duck Hepatitis B virus as the surrogate)
Hepatitis C Virus (Bovine Viral Diarrhea virus as the surrogate)
Herpes Simplex Virus Type 1
Herpes Simplex Virus Type 2
HIV Type 1 Strain HTLV III_B
Human Coronavirus
Influenza A Virus (Hong Kong Strain)
Influenza B Virus
Norovirus (Feline Calicivirus as the surrogate)
Pandemic Influenza A Virus H1N1
Parainfluenza Virus Type 3
Respiratory Syncytial Virus (RSV)
Rhinovirus Type-37
Rotavirus (WA strain)
Vaccinia Virus

ANIMAL PREMISES *VIRUCIDAL ACTIVITY IN 1 MINUTE, UNLESS OTHERWISE NOTED

Bovine Viral Diarrhea Virus – 30 seconds
Duck Hepatitis B virus – 30 seconds
Equine Influenza A Virus (H3N8) (EIV) – 30 seconds

This product has demonstrated effectiveness against Influenza Type A₂ (Hong Kong), and is expected to inactivate all Influenza A viruses including Pandemic 2009 H1N1 (formerly called swine flu).

BROAD-SPECTRUM NON-FOOD CONTACT SANITIZER IN 10 SECONDS AGAINST:

Acinetobacter baumannii
Campylobacter jejuni
Enterobacter aerogenes
Enterococcus faecalis (Vancomycin Resistant (VRE))

Escherichia coli O157:H7

Listeria monocytogenes

Pseudomonas aeruginosa

Salmonella enterica (formerly known as *Salmonella choleraesuis*)

Staphylococcus aureus

Staphylococcus aureus (Methicillin Resistant (MRSA))

Mildewcidal Activity – kills the growth of mold and mildew at a 4 minute contact time: *Aspergillus brasiliensis* (formerly known as *Aspergillus niger*) and the odors caused by them when applied to hard, non-porous environmental surfaces.

Mildewstatic Activity – controls and prevents the growth of mold and mildew at a 4 minute contact time: *Aspergillus brasiliensis* (formerly known as *Aspergillus niger*) and the odors caused by them when applied to hard, non-porous environmental surfaces.

Malodor Activity – eliminates odors and odor-causing bacteria on hard, non-porous surfaces in restroom areas, behind and under sinks and counters, and storage areas and other places where bacterial growth can cause malodors.

Directions For Use

It is a violation of Federal Law to use this product in a manner inconsistent with its labeling.

Not for personal cleansing. This is not a baby wipe. Do not flush in toilet.

Animal Housing Facilities in Veterinary Clinics, Hospitals, Farm Premises including, Equine production Farm, Bovine production Farm.

For cleaning and disinfecting the following hard, non-porous surfaces: feeding and watering equipment, utensils, instruments, cages, kennels, stables, catteries etc.

1. Remove all animals and feeds from premises, animal transportation vehicles, crates, etc.
2. Remove all litter, droppings and manure from floors, walls and surfaces of facilities including pens, stalls, chutes, runs and barns occupied or traversed by animals.
3. Empty all troughs, racks, and other feeding or watering appliances.
4. Thoroughly clean all surfaces with soap and detergent and rinse with potable water. Pull towelette from dispenser and wipe hard, non-porous environmental surfaces.
5. All surfaces must remain visibly wet for 1 minute.
6. Allow to air dry or rinse with potable water if necessary.
7. Ventilate buildings and other closed spaces.
8. Do not house animals or employ equipment until treatment has been absorbed, set or dried.
9. Thoroughly scrub all treated feed racks, mangers, troughs, automatic feeders, fountains, and waterers with soap or detergent, and rinse with potable water before reuse.

For Use as a One-Step Cleaner/Disinfectant:

1. Pre-clean heavily soiled areas.
2. Pull towelette from canister and wipe hard, non-porous environmental surfaces.
3. Allow surface to remain visibly wet for 1 minute.
4. Wipe surface dry or allow to air dry.

For Use as a Cleaner and/or Deodorizer

Pull towelette from canister and wipe hard, non-porous environmental surfaces. Allow to air dry.

*KILLS HIV AND HCV AND HBV ON PRE-CLEANED ENVIRONMENTAL SURFACES/OBJECTS PREVIOUSLY SOILED WITH BLOOD/BODY FLUIDS

in health care settings and other settings in which there is an expected likelihood of soiling of inanimate surfaces/objects with blood/ body fluids, and in which the surfaces/objects likely to be soiled with blood/ body fluids can be associated with the potential for transmission of Human Immunodeficiency Virus Type 1 (HIV-1) (associated with AIDS) Hepatitis B Virus (HBV), or Hepatitis C Virus (HCV).

SPECIAL INSTRUCTIONS FOR CLEANING AND DECONTAMINATION AGAINST HIV-1, HBV OR HCV ON SURFACES/OBJECTS SOILED WITH BLOOD/BODY FLUIDS:

Personal Protection: Disposable latex or vinyl gloves, gowns, face masks, and eye coverings must be worn during all cleaning of body fluids, blood, and decontamination procedures.

Cleaning Procedures: Blood/body fluids must be thoroughly cleaned from surfaces and objects before application of this product.

Contact Time: Allow surface to remain wet for 1 minute to kill HIV-1, HBV and HCV and all other organisms listed on the label.

Disposal of Infectious Material: Cleaning materials used that may contain blood/body fluids should be autoclaved and disposed of according to Federal, State, and local regulations for infectious waste disposal.

For Use as a Tuberculocide:

1. Pre-clean heavily soiled areas.
2. Pull towelette from canister and wipe hard, non-porous environmental surfaces.
3. Allow the surface to remain wet for 1 minute. Use additional towelettes if needed to ensure the correct wet contact time.
4. Wipe surface dry or allow to air dry.
5. Change towelette after each use.

To Kill Fungi:

1. Pre-clean heavily soiled areas.
2. Pull towelette from canister and wipe hard, non-porous environmental surfaces.
3. All surfaces must remain visibly wet for 1 minute. Use additional towelettes if needed to ensure the correct wet contact time.
4. Wipe surfaces dry or allow to air dry.

To Kill *Trichophyton mentagrophytes*:

1. Pre-clean heavily soiled areas.
2. Pull towelette from canister and wipe hard, non-porous environmental surfaces.
3. All surfaces must remain visibly wet for 30 seconds. Use additional towelettes if needed to ensure the correct wet contact time.
4. Wipe surfaces dry or allow to air dry.

To Kill Mold and Mildew: Pre-clean surfaces. Wipe product onto non-porous surfaces until completely wet. Allow the surface to remain visibly wet for 4 minutes. Allow to air dry.

To Control Mold and Mildew: Wipe product onto non-porous surfaces until completely wet. Allow to air dry. Repeat application weekly or when growth reappears.

For use as a Broad Spectrum Non-Food Contact Sanitizer:

1. Pre-clean heavily soiled areas.
2. Pull towelette from canister and wipe hard, non-porous environmental surfaces.
3. Allow the surface to remain wet for 10 seconds.
4. Wipe surface dry or allow to air dry.
5. Change towelette after each use.