

Cleaner

Biosolve™ AQUAMAX XL

Cool Cell Pad
Cleaner & Descaler

For use in cleaning and descaling cool cell pads

For use in poultry, turkey, swine, and other animal
confinement

Excellent end-use compatibility with Lanxess
disinfectants

Formulated with biodegradable detergents

PHOSPHATE FREE

FOR INDUSTRIAL AND COMMERCIAL USE ONLY
KEEP OUT OF REACH OF CHILDREN
DANGER/PELIGRO

See side panel for Precautionary Statements



1 Gallon (3.78L)

MADE IN THE
USA
GENUINE
QUALITY
GUARANTEED

LANXESS

Biosolve™ AQUAMAX XL

Cool Cell Pad
Cleaner & Descaler

Components: Water (7732-18-5), Ethoxylated branched C9-11, C10-rich alcohols (78330-20-8), Citric Acid (77-92-9)



DANGER

Hazard Statements: Causes severe skin burns and eye damage.

Precautionary Statements: Wear protective gloves/clothing and eye/face protection. Wash hands thoroughly after handling. IF INHALED: Remove victim to fresh air and keep at rest in a position comfortable for breathing. IF SWALLOWED: Rinse mouth. Do NOT induce vomiting. IF ON SKIN (or hair): Take off immediately all contaminated clothing. Rinse skin with water or shower. Wash contaminated clothing before reuse. IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. Get medical attention immediately.

Store locked up. Dispose of contents and container in accordance with all local, regional, national and international regulations.

Do not taste or swallow. Wash thoroughly after handling. Store in original container protected from direct sunlight in a dry, cool and well-ventilated area, away from incompatible materials and food and drink.

CONSULT SDS FOR FURTHER INFORMATION

LANXESS

Biosolve™ AQUAMAX XL

Cool Cell Pad
Cleaner & Descaler

Biosolve™ AquaMax XL is formulated with biodegradable detergents and organic acids. It is specifically designed for removing soils and mineral scale build-up from cool cell pads. It contains no muriatic, nitric, sulfuric, mineral or oxidizing acids. Biosolve™ AquaMax XL is recommended for use in poultry, turkey, swine, cattle and other animal confinement facilities as a cleaner and descaler for cool cell pads.

DIRECTIONS FOR USE

CLEANING COOL CELL PADS (RECIRCULATING SYSTEMS)

Assure pads are in washable condition. With pump on, add into the sump tank 1/2 ounce of product per gallon of water (4 ml / L). Allow maximum circulation of treatment through the pads for at least one hour. Treatment of heavily soiled pads may take longer, but should not exceed 24 hours. Wash pads with low-pressure garden hose. Drain all water from the system including reservoirs, sump tank and filters. Refill the tank with clean water. To control algae and slime, use an appropriate Lanxess disinfecting solution. Consult a Lanxess Technical Representative for recommendations.

CLEANING COOL CELL PADS (FOGGING SYSTEMS)

Assure pads are in washable condition. Turn pump to pad off. Wet pads with water and then saturate the pad with a solution of 1 gallon of product mixed with 25 gallons of water (4 L / 100 liters). If possible, let stand for at least one hour. Wash pads with low-pressure garden hose or water under pressure. To control algae and slime, use an appropriate Lanxess disinfecting solution. Consult a Lanxess Technical Representative for recommendations.

FOR REVIEW ONLY



MADE IN THE USA

Manufactured for:
LANXESS Corporation
Product Safety & Regulatory Affairs
111 RIDC Park West Drive
Pittsburgh, PA 15275-1112

Emergency phone:
CHEMTREC (800) 424 9300
International (703) 527 3887

Lanxess Emergency Phone:
(866) 673 6350

For Information: US/Canada (800) LANXESS

International: +1 412 809 1000

©2017 LANXESS. BIOSOLVE™ is a trademark of LANXESS Corporation. LANXESS™ and the LANXESS Logo are trademarks of LANXESS Deutschland GmbH registered in many countries worldwide.